




# Huawei P9 Earphone Jack Replacement

This video will show you how to repair the broken Huawei P9 ear phone jack and way to replace a new one.

Written By: Eric

A close-up photograph of the internal components of a Huawei P9 smartphone. A yellow Li-ion battery is visible at the top left, with a warning diagram and the text 'Li-ion 00' printed on it. Below the battery, various electronic components, including a circular silver component and a black component, are visible. The text 'Huawei P9 Headphone Jack' is overlaid in a large, bold, black font across the center of the image.

## Huawei P9 Headphone Jack

## INTRODUCTION

For the official iFixit repair guide, [click here](#). The guide you are viewing is retained for historical purposes only.

[video: [https://www.youtube.com/watch?v=fg4S5l5\\_Pl4](https://www.youtube.com/watch?v=fg4S5l5_Pl4)]

This video will show you how to repair the broken Huawei P9 ear phone jack and way to replace a new one.



### TOOLS:

- [iSclack](#) (1)
- [Tweezers](#) (1)
- [Spudger](#) (1)
- [Phillips #000 Screwdriver](#) (1)
- [iFixit Opening Picks set of 6](#) (1)
- [P2 Pentalobe Screwdriver iPhone](#) (1)



### PARTS:

- [Huawei P9 Headphone Jack](#) (1)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-31 02:49:12 PM.